


ONE TOUCH. TWO SILHOUETTES.

Wake the Starling

A perched bird at rest. A shooting star when it rocks.



IN THE BOX 1 × Starling Gate — one solid piece; nothing to assemble

1

SET

Stand the curved edge on a level, firm desk.

2

TAP

Touch one upper shoulder lightly.

3

WATCH

Let it rock freely.
Do not hold the arch.

READY POSE

The gate is upright and the bird appears perched. If it stops tilted, reset it gently by hand—do not force or bend the arch.



Rock. Reset. Repeat.

THE WHOLE MOVE

- 1 Start upright on the curved edge.
- 2 Give one shoulder a light sideways tap.
- 3 Let gravity bring the gate back to its ready pose.

Rocking rhythm varies with the tap, desk surface, material, and internal fill.

?

ROCKS TOO LONG

Use a lighter tap. Move to a firm, level surface. Keep the curved edge clean and dry.

?

BARELY MOVES

Tap sideways near the upper shoulder. Make sure no object touches the gate as it rocks.

CARE & PACK-AWAY

- Wipe with a soft, slightly damp cloth; dry before use.
- Store flat or upright where it cannot roll or fall.
- Stop using it if the body cracks, chips, or develops a sharp edge.

SAFE PLAY

Use on a clear tabletop, away from edges. Keep fingers clear of the rocking contact. This is a desk object, not a throwing or chew toy.