


TEMPEST LULL

A small storm that settles with a nudge.



IN THE BOX

1 Tempest Lull rocker

One connected piece. No assembly.

CURVE DOWN



SETTLE THE STORM

The fixed bolt moves with the whole rocker.



REST



CREST



RETURN

1

PLACE

Set the crescent keel on a clean, level, hard surface.

2

NUDGE

Tap either cloud cheek gently with one finger.

3

RELEASE

Let go. Watch the framed bolt sweep as the body returns.

RESET & CARE

Let it come to rest; set it upright again if it tips.

Wipe dry. Store indoors, away from heat and sunlight.

IF IT WILL NOT ROCK

Clear grit; check that the surface is level and hard.

Return to center and try a smaller, gentler nudge.

USE SAFELY

Ages 14+. Desk toy, not a children's toy. Do not throw or drop.

Inspect before use; stop using if cracked, sharp, or damaged.

Use on a clear surface, away from edges. Keep the arch unobstructed.