


SHADOW TOY • 2 PIECES

FROSTING ALOFT

A cupcake takes flight.



LOWER • LIFT • REVEAL

Use an external flashlight to cast the silhouette on a pale wall. Slide the frosting to transform a cupcake into a hot-air balloon.

START HERE


MEET THE TWO PIECES

In the box

- 1 Cupcake base
- 1 Sliding frosting cap

ASSEMBLE

Hold the base upright. From above, lower the frosting cap so its two open rear guide cheeks sit around the two guide posts. Keep both sides level and slide down gently.



CAP: OPEN REAR CHEEKS

BASE: TWO GUIDE POSTS


THE TRAVEL STOP

The two large round guide marks are your raised-position cue. Stop when the frosting's lower edge meets both marks.

GENTLE MOTION ONLY

If either side catches, stop. Lower the cap, re-seat both guides, and try again. Never twist or force it.

SET THE LITTLE STAGE



1

Stand it square

Place the flat base upright, broad face parallel to a pale wall. Dim the room.

2

Aim horizontally

Place the flashlight behind the toy, within the shown range. Keep the beam out of eyes.

3

Find the cupcake

With the frosting fully lowered, adjust the toy and light until the cupcake shadow is crisp.

4

Send it aloft

Pinch the cherry and lift straight up. Stop at both round guide marks: posts become ropes and the wrapper becomes the basket.

QUICK FIXES & CARE

SOFT OR DOUBLED SHADOW?

Darken the room and stay inside the distance ranges. Multi-LED phone lights can make doubled edges; try a small single-point flashlight if available.

SHADOW LOOKS SKEWED?

Square the toy's broad side to the wall. Aim the flashlight horizontally through the center of the toy.

CAP BINDS OR TILTS?

Stop, lower it, and check that both guide cheeks surround their posts. Lift evenly by the cherry—never twist or force.

SAFE KEEPING

This is not a lamp; use only an external flashlight. Keep light out of eyes. Lower the cap before packing. Wipe dry, keep away from heat and water, and stop use if cracked.