


EMBER KNOCK

A ONE-FINGER LISTENING RITUAL

Gently wake the table. Listen for what happens.



ONE PIECE

MEET THE SHAPE

The round globe and twin flat pads belong on the tabletop. The broad press cap stays outside the edge. The open saddle wraps around the edge.

IN THE BOX

1 x Ember Knock - one printed body; no assembly


Before the first press, read the setup and safety steps on the back.

SEAT. PRESS. LISTEN.

1 CHOOSE Use a steady, rigid table edge 18-22 mm thick. Clear breakables. Avoid glass, fragile, strongly rounded, or unstable edges.

2 SEAT Slide the open saddle loosely over the edge. Rest the round globe and both flat pads on top; keep the broad cap outboard. Keep a hand ready to catch it.

3 PRESS + RELEASE Press the broad cap gently until the rocker stops, then lift your finger. Do not force it. Catch it if it slips or does not return.



LISTEN CLOSELY

The small underside nub is intended to make the first tap. The broad top pads are intended to make the return knock. Actual sound and gravity return vary by print and surface and have not been physically tested.

IF SOMETHING IS OFF

SLIPS OR FALLS - Stop. Catch it. Try only a clean, flat, rigid edge in the stated range.

NO RETURN - Stop and catch it. Reseat with both top pads flat; do not force motion.

MARKS OR HARSH NOISE - Stop. Protect the surface and press more gently.

CARE + SAFETY

Keep fingers and face clear beneath the edge. This is not a handle: never climb, hang, or pull the table with it. Do not strike near ears. Inspect for cracks; stop using if damaged. Wipe with a damp cloth, dry fully, and store off the edge.